

MOTOROLA EMMI BOX EXTENDED INSTRUCTION

UNLOCKING with MotoFlex special

- 1) Power ON and OFF Emmi Box.
- 2) Run program (MotoFlex) – read phone button will appear on bottom.
- 3) Connect phone via attached cable and push ON for a short time – after 2 sec it will power ON and green LED light on EMMI Box.
- 4) Click READ PHONE – you will see commands sended to EMMI Box and right menu with Motorola scroll will be accessible.
- 5) Click to Motorola-> Advanced Features -> SIM Lock
- 6) Uncheck SIMLOCK and press FLEX PHONE
- 7) Click EXIT and confirm with YES, power OFF phone and disconnect phone.
- 8) Power OF and ON EMMI Box
- 9) Run program (MotoFlex) – read phone button will appear on bottom.
- 3) Connect phone via attached cable and push ON for a short time – after 2 sec it will power ON and green LED light on EMMI Box.
- 4) Click READ PHONE – you will see commands sended to EMMI Box and right menu with Motorola scroll will be accessible.
- 5) Click to Motorola-> Advanced Features -> SIM Lock
- 6) If SIMLOCK box is unchecked your phone is unlocked – click on EXIT and power it OFF then deattach cable.

By using these steps you can change IMEI, wekup logos, reset LifeTimer, read and change security logo and extend menu's like many others. If you got still problem try this solution:

- 1) Read phone
- 2) Go to simlock menu - uncheck option
- 4) Press flex phone and wait 5 sec
- 5) Power off phone and power it again on
- 6) Press flex phone and power off phone
- 7) Go to other menu (not simlock but for example security)
- 8) Power ON phone and press read
- 9) Go to simlock – box must be unchabed and simlock state is OFF

www.techgsm.com